

# **INSTRUCTION MANUAL**

### **TABLE LAMP DRUPOL 21616**

#### **Description of the lamp**

The table lamp DRUPOL 21616 serves as a table lamp for lighting in living and other rooms. A swivel lampshade with a sleeve and a light bulb is mounted on a steel wire leg.

- This lamp is intended for indoor use only.
- Do not cover the switched on lamp.
- Do not make any changes to the wiring.
- Do not touch the mains plug with moist or wet hands.
- We are not liable for damages caused by failure to follow the instructions in this manual. Failure to follow these instructions will cancel the warranty!
- All repairs should be done by professionals with proper authorization.
- The lamp should not be exposed to high temperatures, high humidity, strong vibrations or excessive mechanical stress.
- Water or any other liquid is not supposed to get inside the lamp. In such case there is a danger of fire or injury by electricity. Should it occur immediately pull out the cord from the wall socket and contact the professional.
- Do not leave any flammable objects near the lamp.
- Do not switch on the lamp immediately after bringing it from a cool environment into a warm place. The
  condensed water could damage your lamp. Do not switch on the lamp until its temperature equals the room
  temperature.

### Switching the lamp on and off

This lamp can only be connected to public alternating voltage 230 V / 50 Hz. Other power connection is not allowed.

- Place the lamp on an even surface (e.g. a table).
- Plug it into a mains socket 230 V/ 50 Hz.
- Switch on the lamp by the cord switch.

### Light bulb change

- Before changing the bulb unplug the lamp from the electricity. Leave it to cool sufficiently.
- Do not touch the lighted bulb with bare hands.
- Unscrew the faulty bulb and screw into the bulb socket a new one of the same type: 230 V / 25 W / E14.
- Important notice: Never use a bulb with a higher power than the stated one. When using such a bulb there is a danger of overheating the lamp and a danger of fire.

# Maintenance and cleaning of the lamp

- Before cleaning disconnect the lamp from electricity.
- Be sure that no water or other liquid can get inside the lamp.
- Do not use any aggressive cleaning means or chemical solvents, which could etch the surface of the lamp or influence its function.

# Technical data:

Power: 230 V ~/ 50 Hz

The bulb: 230 V / E17 / max. 25 W Dimensions: height 30 cm, base 17 x 17 cm.